

How to clean and sanitize your Fable modules



As a safety precaution make sure to power off your modules and disconnect any power supply prior to cleaning and/or sanitizing.



Do NOT spray any liquid or disinfectant directly onto the modules.



Moisten a soft, microfiber cloth with a **70% isopropyl alcohol (rubbing alcohol) / 30% water mixture**.

The cloth should be damp, but not dripping wet.

Alternatively, a **70% isopropyl alcohol wipe** may be used, but be sure to wring out any excess liquid.



Gently wipe the cloth on the surface of the modules to be cleaned.



Do NOT allow liquid to drip into the motors.



Allow all surfaces to be completely air-dried before turning the module back on.



To prevent damage to the surface of your module, we discourage the use of cleaners that contain the following substances:

- Chlorine-based cleaner, such as bleach
- Peroxides (including hydrogen peroxide)
- Ammonia, such as Windex
- Ethyl alcohol
- Solvents such as acetone, paint thinner, benzene, methylene, chloride or toluene